



**TEL-TRU
MANUFACTURING CO.**

World-Class Instruments



Thermometers • Pressure Gauges • Transmitters • Accessories

INDUSTRIAL and SANITARY RTDs


Wiring and Installation Instructions for
Industrial models NP100, NT100 and Sanitary models SP100, ST100

Termination Options (SP and NP)


- **AXX (M12 w/Mating Connector) and E00 (M12)**




- **BXX (Strain Relief w/Cable)**




- **CXX (1/2" NPT w/Leads)**



- **DXX (Connection Head) w/Terminal Block A1**




- **DXX (Connection Head) w/Transmitter B1 or B2**



Termination Options (ST and NT)

- **AXX (M12 w/Mating Connector) and E00 (M12) w/Integrated Transmitter Z1**



Installation Instructions

- **Mounting Location**
NP100, NT100 SP100, ST100

a. At angle sections, against the direction of flow.
b. In smaller pipe, against the direction of flow.
c. Perpendicular to the direction of flow.

Refer to www.teltru.com/rd_trans.asp for temperature and pressure limits.

Tel-Tru Manufacturing Company

408 Saint Paul Street, Rochester, New York 14605 • PO Box 30144, Rochester, New York 14603-3144
Phone: 585.232.1440 • 800.232.5335 • Fax: 585.232.3857
Email: info@teltru.com • Web: www.teltru.com

www.teltru.com
01204012