



Tel-TruTM
Tel-Tru[®] Manufacturing Co.

Thermometer - your 5th Ingredient


MBAA District Western NY
April 2014
Yvonne O'Brien, Tel-Tru Mfg Company

4/28/2014



Thank you for this opportunity to present to your group. A little background, I have worked for Tel-Tru for over 30 years learning the manufacturing process and helping customers with their thermometer requirements. Tel-Tru manufacturers temperature & pressure instruments, both mechanical and electronic. Tel-Tru is 98 years old and our factory is right across the street on St Paul.

Your beer batch take weeks to process and during the process you are changing and monitoring your temperatures so that your brew has the right body, the right mouth feel, and the right alcohol level for the style of beer that you are making. You measure temperature at every step of the brewing process from drying the grain to fermentation and storage so your Thermometers are pretty darn important...your 5th ingredient.



Tel-Tru® Manufacturing Co.

Temperature Instruments in Microbrewery and Commercial Brewery

Small Microbrewery	Larger Microbrewery or Commercial Brewery
Local Indication	Remotely wired to programmable computerized or logic control system with Local Indication for back-up
<ul style="list-style-type: none"> •Bimetal Thermometers •Digital Thermometers •Glass Industrial Thermometers (being phased out) 	<ul style="list-style-type: none"> •<u>Remote Instruments</u> <ul style="list-style-type: none"> •Temperature Transmitter •RTD probes •Thermocouples •Thermistors •<u>Local Indicators:</u> <ul style="list-style-type: none"> •Bimetal Thermometers •Digital Thermometers

4/28/2014

2

The instruments you use are as important as the ingredients...Accurate and controlled temperatures during your brewing process will contribute to making a great beer. From setting the sparge and mash temperatures to fermentation and storage. Your thermometer selection is a basic ingredient to making your brew a success.

In the larger microbreweries and commercial breweries I find electronic temperature instruments that are remotely wired to an electronic display or logic control system. In addition they have local temperature indicators for comparison and back-up. The smaller micro-breweries may only use local indicators such as bimets or digital thermometers.

 Tel-Tru[®] Manufacturing Co.

What's important...

Accurate?
Repeatable?
Durable?



4/28/2014

3

The photo on the right is of an electronic temperature probe with quick disconnect wire that leads to an electronic display panel. The photo on the left shows a bimetal thermometer for local indication. Everyone wants a thermometer that is accurate, repeatable, and durable for their process. Most people tend to forget response time and easy maintenance until after they purchase their thermometers.



Tel-Tru® Manufacturing Co.

Selecting a Thermometer...

- Differences between Electronic & Bimetals
- Accuracy vs Precision
- Calibration
- Maintenance
- Thermowell fit



4/28/2014

4

I am going to cover a few differences between electronic & bimetal thermometers. I will explain accuracy vs precision, and do a light overview on calibration, maintenance, and Thermometer & Thermowell fit.

The images on the bottom left shows 2 different digital thermometers with different housings and possibly different temperature sensors.

 Tel-Tru® Manufacturing Co.

RTD vs Bimetal

RTD Temperature Probes	Bimetal Thermometers
DC Power	Self Powered
Local & Remote reading	Local reading
Displayed number	Pointer positioning
(Ω) R vs T	Angular deflection

4/28/2014

5


RTD temperature probes are widely used because of their accuracy and repeatability. RTD's are typically made with platinum wire elements, an electrical resistance source. An electronic circuit is used to convert the resistance value into a temperature reading. The change in electrical resistance is indicated as a temperature reading on a digital display or meter.

Bimetal thermometers are widely used for local monitoring because they do not require any electrical power and are quite durable. The sensing element is constructed out of 2 dissimilar metals fused together and wound into a helix coil. The bimetal coil will expand and contract with change in temperature. The angular deflection is measured and matched to a dial graduation layout.

RTD & Bimetal sensors require that the entire sensing element be immersed into the process for accurate readings.

 Tel-Tru[®] Manufacturing Co.

Accuracy vs. Precision/Repeatability



4/28/2014

5

Targets are visual aid to show...

Accuracy, the location of the dots compared to the center of the target


Precision, the spread of the dots and how they vary from each other.



Tel-Tru® Manufacturing Co.

Low Accuracy & Low Precision/Repeatability

Thermometer +/- 2°F (38°F to 42°F)



Accuracy	Bad
Precision	Bad
1	43.0
2	42.5
3	44.0
4	45.5
5	43.5
6	41.0
7	44.5
Ref. Temp.	40°F
Avg	43.43
Std Dev (σ)	1.456
6σ	8.734

4/28/2014

7

Accuracy = reading compared to the mfrs accuracy spec. (Target dot location in relation to the center of the target)

Precision = reading variation (Target dot spread)

Standard deviation = how much variation exists in the readings. When the data points are spread apart the standard deviation is great.

Six Sigma = 6x standard deviation and I am looking for a number that is equal or less than the thermometer tolerance number. For this example I indicated the thermometer tolerance as \pm 2 degrees F.

Exercise method: 1 thermometer is tested 7 times in a certified bath temperature that is 40°F and readings recorded.

Readings of this thermometer varied from 41°F to 45.5°F, This thermometer has bad accuracy because the average reading is 43.43°F.

The thermometer also has bad precision because the readings vary greatly from each other.


6 Sigma = 8.734 and is greater than \pm 2 degrees F so we know that our precision is bad.



Tel-Tru® Manufacturing Co.

High Accuracy & Low Precision/Repeatability

Thermometer +/- 2°F (38°F to 42°F)



4/28/2014

Accuracy	Good
Precision	Bad
1	42.5
2	39.0
3	39.5
4	40.5
5	39.0
6	38.0
7	41.5
Ref. Temp.	40°F
Avg	40.00
Std Dev (σ)	1.581
6σ	9.487

8

Accuracy = reading compared to the mfrs accuracy spec. (Target dot location in relation to the center of the target)

Precision = reading variation (Target dot spread)

Standard deviation = how much variation exists. When the data points are spread apart the standard deviation is great.

Six Sigma = 6x standard deviation and I am looking for a number that is equal or less than the thermometer tolerance number of ± 2 degrees F.

Exercise method: 1 thermometer is tested 7 times in a certified bath temperature that is 40°F and readings recorded.

Readings of this thermometer varied from 38°F to 42.5°F. This thermometer has good accuracy because the average reading is 40°F.

The thermometer has bad precision because the readings still vary too much from each other.

6 Sigma = 9.487 and is still greater than ± 2 degrees F and confirms our precision is bad.



Tel-Tru® Manufacturing Co.

Low Accuracy & High Precision/Repeatability

Thermometer +/- 2°F (38°F to 42°F)

low accuracy
high precision

Accuracy	Bad
Precision	Good
1	43.5
2	43.0
3	43.5
4	43.0
5	43.0
6	43.5
7	43.0
Ref. Temp.	40°F
Avg	43.21
Std Dev (σ)	0.267
6σ	1.604

4/28/2014

g

Accuracy = reading compared to the mfrs accuracy spec. (Target dot location in relation to the center of the target)

Precision = reading variation (Target dot spread)

Standard deviation = how much variation exists. When the data points are spread apart the standard deviation is great.

Six Sigma = 6x standard deviation and I am looking for a number is equal or less than the thermometer tolerance number of 2 degrees F.


1 thermometer tested 7 times and its temperature reading recorded each time.
The certified reference temperature is 40F.

Readings of this thermometer varied from 43F to 43.5F. This thermometer has bad accuracy because the average reading is 43.21F and outside its accuracy tolerance. Yet, the thermometer has good precision because the readings are fairly repeatable without much variation. The 6 sigma number is 1.604 and is less than the 2 deg F spec. which means that this thermometer has repeatability.



High Accuracy & High Precision/Repeatability

Thermometer +/- 2°F (38°F to 42°F)



Accuracy	Good
Precision	Good
1	40.0
2	40.5
3	40.0
4	40.0
5	40.5
6	40.0
7	40.0
Ref. Temp.	40°F
Avg	40.14
Std Dev (σ)	0.244
6σ	1.464

4/28/2014

10

Accuracy = reading compared to the mfrs accuracy spec. (Target dot location in relation to the center of the target)

Precision = reading variation (Target dot spread)

Standard deviation = how much variation exists. When the data points are spread apart the standard deviation is great.

Six Sigma = 6x standard deviation and I am looking for a number is equal or less then the thermometer tolerance number 2 degrees F.

1 thermometer tested 7 times and it's temperature reading recorded each time.
The certified reference temperature is 40°F.

This thermometer has Good accuracy and Good precision because the thermometer average reading is 40.14 and the readings have very little deviation from each other.

6 Sigma = 1.464 and is less then the manufacturing tolerance 2 degrees F. so again this thermometer is repeatable which means that it is precise.

Your reference temperature device should be at least 4x more accurate then the accuracy standard of the thermometer being tested. When taking the reading of the tested thermometer you need to include the accuracy tolerance of the reference device in the total variable number. So if your tested thermometer tolerance is \pm 2 Deg F and the reference device is \pm 0.5 Deg F, your total accuracy = 2.5 Deg F.

You can improve the quality of a process by reducing variation.

 Tel-Tru[®] Manufacturing Co.

Thermometer Maintenance

- Handle with care & look for signs
 - Water inside display
 - Bent probe, dents or pry marks
 - Cracked lens
 - Corrosion, rust
 - Calibration frequently needing to be reset



4/28/2014

11

Thermometers are calibrated instruments – that need to be handled with care. Look for visible signs of a problem such as water inside the case.

The photo of the thermometer with water inside the case was taken at a brewery. The thermometer may be fine right now but the water inside will cause deterioration of the internal components and the thermometer will need to be replaced at some point and ideally without affecting your brew.

If you are resetting calibration frequently you may also have a problem thermometer.



Tel-Tru® Manufacturing Co.

Verify Accuracy

- Is your thermometer in tolerance to the manufactured accuracy specification?
- Do you have the right equipment to check accuracy?
- Are your thermometers field resettable or does the manufacturer need to reset the calibration?

4/28/2014


12

When considering thermometer calibration you will need to know...

The accuracy spec stated by the manufacturer.


Do you have traceable or a known reference to compare your thermometer accuracy to?

If the thermometer is out of accuracy can you reset the accuracy?



RTD sensors are specified according to their resistance in ohms at zero degrees Celsius. A PT100 element measures 100 ohms at 0° C . The electrical resistance measured in ohms increases as temperature increases. Prompting a repeatable resistance versus temperature relationship.

The DIN standard class A sensor is fairly common in USA. Once you mate the sensor with a transmitter or display you move into your system accuracy.





The accuracy curves for bimetal thermometers is shown in this chart. The Grade A = +/- 1% full span and is common in the USA. The grade AA is achievable by manufacturers that make their own bimetal coils.



Tel-Tru[®] Manufacturing Co.

Calibration...



A few degrees separate a good beer from a GREAT beer!

4/28/2014

15

Consideration for Accuracy verification and calibration:

Do you have a reference device with certified traceable accuracy such as ASTM thermometer or Dry block calibrator?

When preparing ice bath or boiling water, do you use distilled water and ice cubes?


The impurities in tap water can lower the temperature, especially important when using a boiling water method for calibration.

Can you agitate the liquid baths to ensure you have temperature consistency around the sensor?

Do you have full immersion of the sensor into the liquid bath or dry block temperature zone. Do you know where your sensor is located and its length inside the probe or stem. Make sure the sensor stays fully immersed while making calibration adjustments.

With ice or boiling water, you will need to ensure that you complete your calibration process without interruption. Dry block calibration or electronic calibration baths allow you more freedom and less error prone.

Boiling point is 212°F at 0 feet above sea level. Make sure that you consider the altitude of your location as well as the barometric pressure at the time of calibration.



Water Altitude Boiling Point

Location	Altitude compared to Sea Level	Boiling Point At a barometric pressure of 29.92 inches of mercury (standard pressure at sea level)
Rochester NY	505 ft	211°F
NY State (mean)	1,000 Ft	210°F
Mt. Marcy	5,343 ft	202°F
Atlantic Ocean	0 ft	212°F

References:
http://www.netstate.com/states/geography/mapcom/ny_mapscom.htm
<http://www.csgnetwork.com/h2oboilcalc.html>

4/28/2014

16


This chart outlines locations in New York state and the altitudes and boiling points using the barometric pressure 29.92 inches of mercury (standard pressure at sea level). As the pressure rises so does the boiling temperature point. At 30.19 hg your boiling point in Rochester NY would be 212.5F


TEL-TRUTM

Tel-Tru® Manufacturing Co.

How Easy is your Electronic Thermometer to Reset?

- Software
- Cable
- Firmware updates



The screenshot shows the 'Settings' tab of the software. Under 'General', the 'Tag' is set to 'TST_12', 'Calibration Date' is '2013 / 6 / 23', and 'Computer Date' is visible. Under 'Display Setting', the 'Decimal Point' is set to '0 0 0'. On the right, the 'Calibration' section shows '1 Point Calibration' with an 'Adjustment' slider and 'Fine' radio button selected. Below it, '2 Points Calibration (Optional)' shows two points: '1. First Point: 0.0 °C Read' and '2. Second Point: 100.0 °C Read'. A 'Process' button is also present. At the bottom are 'Reset Digi-Tel to Factory Settings' and 'Return' buttons.


4/28/2014

17

Digital thermometers may be field re-calibrateable. Check with your manufacturer to learn availability. You may also want to confirm if there are any firmware updates for your electronic thermometers.

 Tel-TruTM
Tel-Tru[®] Manufacturing Co.

How Easy is your Bimetal Thermometer to Reset?



4/28/2014

18

Pictures show thermometers with external reset feature. The image on the right is a bimetal thermometer with a slotted screw that is located at the back of the case. You will need to tilt the case to position your screw driver when resetting. The image on the left shows a bimetal thermometer with the reset hole located at the side of the case which allows the user to more accurately read the pointer position while doing the calibration adjustment.



Tel-Tru[®] Manufacturing Co.

Thermowells



- Protection
- Closed process

4/28/2014

19

Installing a thermowell will help protect your thermometer and allow you to remove the thermometer without shutting down your process or draining your tank. A Thermowell is a drilled out piece of solid metal barstock that is machined with a process connection and shank suitable to the process conditions and fit with your instrument.

 **TEL-TRUTM**
Tel-Tru® Manufacturing Co.

Thermowell Insertion and Instrument Selection




4/28/2014

20

Image shows a thermowell shank inside a mash tank. This portion of the thermowell is called the insertion length. Be sure to consider the ideal location and position for your Thermowell before installation. You also want to ensure that there are no moving parts inside the tank that will come in contact with the well.

 Tel-Tru[®] Manufacturing Co.

Thermowell Dimensions



4/28/2014

21


These illustrations show a well with and without a lagging extension. A lagging extension is common when there is insulation or you want the head of your instrument further away from the process.

Stepped and tapered shanks are common specified to improve temperature transfer and response time

The insertion dimension is measured from the underside of the process connection. The instrument stem length is based on the Thermowell overall length less the well tip.

 Tel-Tru[®] Manufacturing Co.

Thermowell & Thermometer Fit



- Air Gap
- Instrument sensor location within your well & process

4/28/2014

22

Temperature transfer from the thermowell to thermometer can be slowed by the air gap between them, and delay the thermometer reading response time.

Most USA thermometers have a 0.250" probe diameter and the thermometer instrument ID is 0.260". European instruments are more commonly manufactured with a 0.236" probe diameter and installed into a 0.260" bored Thermoewell. To improve the temperature transfer you can use a heat transfer compound around the thermometer probe covering the area where the sensing element is before inserting the thermometer into the thermowell. A bimetal thermometer sensor is commonly 2 to 3" long and located at the end of the probe. Bimetal thermometer probes have a groove or dot indented into the probe to indicate where the sensor begins. The RTD sensor is commonly $\frac{3}{4}$ " to 1" long and located at the end of the probe.

Be sure that your thermometer sensor is completely inside the 'u' area of the thermowell and inside the process so that it is exposed to the process.

The slide features the Tel-Tru Manufacturing Co. logo at the top left, which includes a red circle with 'TEL-TRU' and a TM symbol, followed by the company name in a serif font. At the top right is a large, stylized thermometer graphic with the word 'TEL-TRU' across it. The main headline 'The Right Temp for the Right Brew!' is centered in bold black text. Below the headline is a photograph of three people (two men and one woman) smiling and holding small glasses of beer. They are standing behind a dark wooden counter that holds a wooden tray with several glasses of beer at different temperatures. The background shows an industrial or brewery setting with pipes and equipment.


TEL-TRU
Tel-Tru® Manufacturing Co.

The Right Temp for the Right Brew!

4/28/2014

23

I hope that the information helps you in having “The Right Temp for the Right Brew!”



The slide features a dark purple background with a faint, stylized graphic of a clock face and wavy lines. In the top left corner, there is a circular logo with the word "TEL-TRU" in white, surrounded by a red ring with a small "TM" symbol. To the right of the logo, the text "Tel-Tru® Manufacturing Co." is written in a white, sans-serif font.

Questions?

4/28/2014 24

Tel-TruTM Manufacturing Co.

Thank You!



Rich Michaels,
MBAA District Technical Chair



Genesee Brew House

4/28/2014

25

Thank you Rich Michaels and the Genesee Brewhouse for allowing me the opportunity to present at your MBAA event.



The image shows a group photograph of the Tel-Tru Manufacturing team. The group is posed in three rows against a brick wall in an industrial-style building. In the foreground, a blue banner with the company's name is visible. The background features a large circular graphic with the Tel-Tru logo and the text "Tel-Tru Manufacturing Co." The date "4/28/2014" is printed at the bottom left, and the page number "26" is at the bottom right.

TEL-TRU
Manufacturing Co.

Tel-Tru® Manufacturing Co.

Tel-Tru Manufacturing team

4/28/2014

26

Please visit our websites for more information:
www.TelTrubrew.com
www.TelTru.com